



IDEAL WALLSTIK SKIM COAT.

PRODUCT DESCRIPTION:

Ideal WALLSTIK SKIM COAT is premium cement- based wall putty specially developed as a base coat to cover unevenness and pinholes in plastered surfaces and to make the walls/ceilings ready for painting.

PRODUCT BENEFITS:

1. Provides superior smooth and uniform finish to rough plaster, which effectively reduces the consumption of paint.
2. Good workability.
3. Does not require curing with water.
4. Good water resistance.
5. It has excellent bonding to the base plaster/concrete walls and ceiling.
6. Excellent strength and abrasion resistance.
7. Controlled water vapor permeability.
8. Can be applied on interior and exterior walls and ceilings.
9. Resist growth of algae and fungi on wall.
- 10.** No need to apply any kind of primer before application of this putty.

SURFACE PREPARATION:

Ensure that the surface is completely free from all dirt, loosely held plaster, powdery residue, oil, grease, or any other contamination. Any previous growth of fungus, algae, or moss needs to be removed thoroughly by vigorous wire brushing and cleaning with water. One coat of fungicidal wash is recommended. In case of cracks, holes, dents in on the base plaster, it should be repaired. Pre-wet the surface before application of putty.



PREPARATION OF IDEAL WALLSTIK SKIM COAT:

Slowly mix Wallstik Skim Coat with 35-40% clean water to make a paste. Add the water to the powder and not VICE –VERSA. Preferably use mechanical stirrer for mixing paste, mix thoroughly for 10-15 minutes to get a smooth uniform paste. Allow the paste to stand for 5-10 minutes and then mix again for 5 minutes. Only prepare quantity which can be used within one hour after mixing water. Stability of mixed paste is 1.5 hours.

COVERAGE:

On rough masonry surface by putty knife/steel trowel, for 2 coats is 1 -1.5 square meters per kg for up to 1.5 mm thickness in 2 coats. The coverage area however will depend upon the nature of the surface and skill of applicator.

APPLICATION:

1. Sand the surface with sand paper and wipe clean to remove dust
2. Pre-wet the surface with water before application of the paste.
3. Apply 1st coat of Wallstik Skim Coat vertically using steel trowel at a thickness approximately 1mm.
Allow it to dry for 4-5 hours. After drying first coat of, just rub the surface with wet sponge or very gently with the putty blade in order to remove the loose particles.
4. Then apply second coat of Wallstik Skim Coat Horizontally. Allow it to dry overnight (10-12 hours). **Total thickness of coats should be restricted to a maximum of 2mm.**

STORAGE:

Store in a cool dry place away from rain or sunlight.

PACK SIZE: 1kg, 5kg & 25kg.